


This is a simplified user's manual of 2-dimension scanner. You can read the manual's barcode by the scanner to change your scanner's setting. If you need more technical support, you may contact the local distributor or download the advanced version user's manual in the website.

# User's manual of 2-dimension Scanner



“★” Default Settings

## System Setting



Return to factory default



Display firmware version

## Scan Mode



★Trigger Mode



Auto Scan Mode

## Interface Settings



Set to RS-232 port



Set to USB port



USB virtual COM port

\* This function need to install the driver




Always on



Always Off


## Barcode Conversion Settings



UPC-A convert to EAN13



★UPC-A convert to EAN13 disable



Exit  
Programming  
Mode




★Enable QR mirror decoding



★Return to default setting




Pharmacode enable



EAN 13 convert to ISBN




Disable QR mirror decoding



EAN13 disable



RSS14 disable




★Enable DataMatrix mirror decoding



CODE 128 disable



PDF417 disable




★EAN 13 convert to ISBN disable




Disable Data Matrix mirror decoding



Codabar disable




QR disable



Enable Code 39 full ASCII mode

## Symbology Configuration



★Disable Code 39 full ASCII mode



Enable all



Interleaved 2 of 5 disable

